Kodak EasyShare zoom digital camera

CX7330

Amazing picture quality

- Get amazing-quality prints up to 11" x 14" with 3.1 MP
- Zoom in close with its premium all-glass Kodak Retinar 3X optical zoom lens and 3.3X advanced digital zoom
- Capture great-looking pictures, even in low light, with multi-zone auto-focus
- Get true-to-life color quality with Kodak color science

Incredible ease of use

- Easy-to-access scene and color modes for consistently great shots
- See your pictures the way you shot them with auto picture rotation
- Catch all the action using the continuous video with audio capture
- Don't miss a shot – snap a picture in any mode

The simple way to share

- Print, e-mail, and organize your pictures with ease using the exclusive on-camera Share button
- Powerful yet simple-to-use Kodak EasyShare software
- View your pictures – even in bright sunlight – with its 1.6" indoor/outdoor display
- Compatible with Kodak EasyShare camera and printer docks*

"All I want are great-looking pictures." Sound familiar? Then you're going to love the sound of this: The Kodak EasyShare CX7330 zoom digital camera captures vibrant, crisp, amazing-quality pictures with point-and-shoot ease. And since it's part of the EasyShare system, every step of the digital process is remarkably simple.

Just press share™

Everything you need to capture every moment.

CX7330

The only thing easier than using the CX7330 is being impressed by the pictures you take with it. So start shooting! There are memories to capture.

3.1 megapixels
You're sure to be impressed by what 3.1 MP can deliver – rich, vibrant prints from 4" x 6" up to 11" x 14".

Premium, all-glass Kodak Retinar 3X optical zoom lens
Get in close for the moments that matter. With the CX7330, your pictures will be crisp and precise.

Multi-zone auto-focus
Have several subjects in one picture? Shooting in dim light? The CX7330 captures great-looking pictures thanks to its multi-zone auto-focus.

Kodak color science
With Kodak color science, colors are consistent and vibrant, flesh tones are accurate, and pictures are sharp.

Automatic picture rotation
No more twisting and turning your camera to view your pictures. When you snap a vertical picture, it will appear on the display vertically.

Always ready capture mode
Never miss a picture-taking moment. The CX7330 is always ready to shoot – no matter what mode it is in.

Continuous video with audio
Some moments are better in motion. For those, the CX7330 features continuous video with sound.

16 MB internal memory, SD/MMC expansion slot
The CX7330 comes with 16 MB of internal memory, so you can start shooting right away. Want more memory? Use an optional SD/MMC card for even more picture-taking power.

On-camera Share button
Have a picture you know you'll want to share? Tag it using our exclusive Share button. Next time you place your CX7330 in its Kodak EasyShare printer or camera dock, your picture is ready to print or e-mail.

1.6" indoor/outdoor display
See your pictures even in direct sunlight – the big, bright indoor/outdoor display makes it simple to share your pictures right after you take them.

Multiple scene modes
Let the CX7330 take care of the details. In addition to auto mode, it also features five more modes to choose from depending on your shot.

Auto – Ideal for most picture-taking situations, it automatically adjusts your settings for a great shot.

Sport – Ideal for fast-moving subjects, the CX7330 captures action without blurring.

Landscape – Select this setting for distant shots and broad vistas.

Close-up – Pictures are detailed and in focus when shooting up-close.

Night – Ideal for night scenes or low-light situations.

Color – Get creative with color modes. Choose from color, black and white, and sepia.

Print whenever, wherever.

With all the printing options Kodak offers, you can choose the method that works for you. So you're always just a few simple steps away from getting great prints.

At home
Printing at home is a quick, convenient way to get prints from your digital camera. Use the EasyShare printer dock for real Kodak 4" x 6" photos, or Kodak inkjet photo papers for Kodak quality prints from your inkjet printer.

Online
Kodak EasyShare software makes it simple to share photos online. Simply select an online service that lets you easily organize your pictures into albums for sharing and printing.

At a store
With our convenient in-store kiosks, getting prints from your digital camera has never been easier. Look for the Kodak Picture Maker kiosk at a local store.

3.1 MEGAPIXEL | 11"x14" 28x36CM MAXIMUM PRINT SIZE | 3X OPTICAL ZOOM 3.3X ADVANCED DIGITAL 10X TOTAL ZOOM | share SHARE BUTTON | MULTI SCENE MODES | VIDEO/AUDIO | AF LOW LIGHT AUTO FOCUS | INDOOR/OUTDOOR DISPLAY | AUTO PICTURE ROTATION | 16MB INTERNAL MEMORY | COMPATIBLE WITH *EASYSHARE* DOCKS

Making digital even simpler

The optional Kodak EasyShare printer dock is the simplest way to go from picture to print. Just dock your Kodak EasyShare digital camera, touch the button, and get real Kodak borderless 4" x 6" prints. It even works with or without a computer. And just like the optional Kodak EasyShare camera dock 6000, the printer dock transfers pictures from camera to computer at the touch of a button and recharges your Kodak camera battery in less than 3.5 hours**.

CX7330

Standard Features
CCD – 1/2.7 inch type (3.3 M total pixels)
Effective pixels – 3.1 megapixel
(2032 X 1524 pixels)
Image quality
3.1 MP – best (prints up to 11" x 14")
2.8 MP – best 3:2 (optimized ratio for 4" x 6" prints)
2.1 MP – better (small prints)
1.1 MP – good (email)
Still format JPEG/EXIF v 2.2
Lens – 3X optical zoom
5.6-16.8 mm (35 mm equivalent: 37 - 111 mm)
Advanced digital zoom – 3.3X
Aperture – f/2.7-5.2 (wide), f/4.6-8.7 (tele)
Shutter speed – 1/2-1/1400 sec.
Real image optical viewfinder
LCD – 1.6" (4 cm) TFT indoor/outdoor color display

Performance Features
Scene modes – auto, sport, night, landscape, close-up
Photo settings – color, black and white, sepia
Burst mode – 3 fps, up to 3 pictures
Click to capture - 0.7 sec.
Video mode – continuous video with audio capture
Video resolution – QVGA (320x240 pixels) at 15 fps
Video length – continuous up to 80 min. limited by capacity of external memory card
Video format – Quicktime MOV
Auto focus – multi-zone TTL-AF
Focus range
Standard – 60 cm (23.6 in.) to infinity
Close-up wide – 13-70 cm (5-28 in.)
Close-up tele – 22-70 cm (9-28 in.)
Sensitivity – ISO equivalent 90 – 180 (automatic)
White balance – auto
Exposure metering – TTL-AE; multi-pattern
Exposure control – programmed AE
Exposure compensation – +/-2.0 EV in 0.5 EV step increments

Ease-of-Use Features
Built-in flash – auto, red-eye, fill, off
Flash range
wide – 0.6-3.6 m (2-11.8 ft.)
tele – 0.6-2.1 m (2-6.9 ft.)
Review options – magnify (2X, 4X, pan), slide show, multi-up, protect, album, copy
Auto picture rotation
Software – Kodak EasyShare software
Storage – 16 MB internal memory, SD/MMC card expansion slot
Self-timer – 10 seconds
Dock compatibility - Kodak EasyShare camera docks, Kodak EasyShare printer docks*

Additional Features
Power options – optional Kodak EasyShare docks** with Ni-MH rechargeable battery pack; 2 AA Kodak Max digital camera batteries; 2 AA lithium or Ni-MH batteries or 1 CRV3 lithium battery; 3 volt DC
Lens protection – built-in lens barrier
Tripod mount – 1/4 in. standard
I/O interface – power input (3V DC), A/V output (NTSC or PAL, user selectable), Kodak camera dock/printer dock interface, USB compliant connector
Weight – without batteries: 175 g (6.2 oz.)
Dimensions – WxHxD: 102.5x65x38 mm (4.0x2.6x1.5 in.)
Warranty – one year

Minimum System Requirements
Windows 98, 98SE, ME, 2000 SPI, or XP OS
Internet Explorer 5.01 or higher
233 MHz processor or greater
Macintosh OS X 10.2.3, 10.3
Safari 1.0 or higher

Minimum Hardware Requirements
128 MB RAM (64 MB RAM for Windows 98, 98SE, 2000 SP1, ME OS)
200 MB hard drive disk space available
CD-ROM drive
Available USB port

Package Contents
Kodak EasyShare CX7330 zoom digital camera
Kodak Max digital camera batteries AA or equiv.
USB cable
Wrist strap
Kodak EasyShare software
Getting Started kit
Custom camera insert for optional Kodak EasyShare camera and printer docks

Recommended Accessories
Kodak EasyShare printer dock
Kodak color cartridge and photo paper kit
Kodak EasyShare camera dock
Kodak SD memory card, 128 MB
Kodak EasyShare Ni-MH rechargeable battery pack
Kodak audio/video cable
Kodak EasyShare travel kit
Kodak 8-in-1 card reader

*Compatible with optional Kodak EasyShare printer and camera docks, except printer dock 4000 and camera dock II.
**Actual battery charging time may vary by camera model

Exif Print | USB

Kodak Worldwide Sponsor

©Eastman Kodak Company, 2004. Kodak, EasyShare, Max, Retinar, the Share button, and Share Moments. Share Life. are trademarks of Eastman Kodak Company. Product specifications subject to change without prior notice. Simulated images.

Share Moments. Share Life.™

Kodak